Control Panel:



- **Button description:**Switch button: Plug in the power supply, and the buzzer sounds once, Press this button to enter the standby state; Press this button again to shut off.

 Mode button: Press this button to select desired program.
- "+": Press this button to increase time.
 "-": Press this button to decrease time.

- Make sure the items to be sterilized are suitable for sterilizer.
- 2. Clean the bottles and other items to be sterilized thoroughly.

 3. Make sure the appliance is installed correctly, and connect the power cord to the power outlet.
- 4. Pour around 100mL water on the stainless-steel plate, it is not necessary to pour any water for dry function.
 5. Press switch button to enter to standby state, LED screen displays" 00".
 6. Press mode button to select the desired program, "Auto-Sterilize-Dry-Keep" cycling switch, It will switch to
- the indicated mode after 3 seconds flashing.

 7. After selecting the mode, press the "+" " " button to adjust the time, press once to increase/decrease 1min for Sterilize and Dry functions, and 1 hour for Keep function.

 8. Adjustable time table.


Mode	Default Time	Adjustable Time Range
Auto	Sterilizer-Count, Dry-Countdown	
Sterilize	18min	8-25min
Dry	45min	10-60min
Keep	24h	

Tips: Under Keep function, dry function will run 10min per 3 hours. E1: Water less than 100mL, unplug to reset the machine.

DISTRIBUTED BY: BLUERISE INTERNATIONAL LLC For customer support, E-mail:blueriseinternational@gmail.com

BRBluerise

Steam sterilizer and dryer



BLUERISE INTERNATIONAL LLC

- Do not disassemble the base to avoid the risk of electric shock.
- 2. Do not allow children to use the appliance. Keep the appliance out of the reach of children.

 3. If the power cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly
- qualified person in order to avoid a hazard.
- 4. The lid of the appliance becomes hot during operation or shortly after operation and may cause burn if it is
- 5. Hot steam coming out from the vent in the lid or when the lid is opened may cause burn. Do not get dose to it.6. Do not move the product or open the lid when it is in use.
- 7. Do not move the appliance until it cools down.
- 8. This appliance is not to be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

 9. Do not allow children to play with the appliance.
- 10. The stainless-steel heater plate becomes hot during operation or shortly after operation and may cause burn if it is touched.

- This appliance is intended for household use only. Do not use outdoors.
- 2. Make sure the voltage indicated on the appliance corresponds to the local mains voltage before connecting the appliance.
- 3. Do not sterilize the bottles and other items which are not suitable for sterilizers. Make sure the items to be sterilized are suitable for steam sterilization.
 4. Do not use the appliance if the power cord, plug or the appliance itself is damaged.
- 5. Do not use the appliance once fallen or is damaged in any way.

- 6. If there is any visible damage to the appliance, unplug it immediately and stop using it.

 7. Make sure the appliance is installed correctly, or it may not start.

 8. Do not start sterilization if no water in the stainless steel heater plate. Or it may cause damage to the
- appliance. Make sure to pour around 100ml water into the stainless steel heater plate before sterilization.

 9. Only use water without any additives. Can use distilled water (pure water) or filtered water to avoid scale
- build up. Do not use mineral water or electrolyzed water.
- 10. Do not cover the vent in the lid during sterilization or drying. 11. Environmental conditions such as temperature and humidity may affect the drying effect. If there is still
- water residue, dry again by selecting 10 minutes drying only or let it dry naturally.

 12. Follow the cleaning instruction to clean the scale on the stainless-steel heater plate, or it may cause
- malfunction and odors.

 13. Pour out any remaining water from the stainless steel heater plate after cleaning. Do not let water flow
- into the air outlet.
- 14. Do not immerse the base, the power cord or plug in water or any other liquid.
- 15. Clean the filter regularly. Remove it from the base and rinse with running water. Put it back when it is dry. 16. Unplug the appliance after use.

 17. Keep the appliance away from heat source and direct sunlight.


- 18. Do not place items on top of the appliance when it is in use.

 19. Do not start another sterilization circle soon after one sterilization circle is finished, let the appliance cool down first. Or it may not be started.

This product is an indoor household appliance. It can be used to sterilize and dry items. The steam sterilizer can effectively kill 99.9% of germs. It takes about 15 minutes for sterilization and 45 minutes for drying

Product Name	Steam Sterilizer and Dryer
Product Model	HJ-E04
Rated Voltage	110V-120V
Rated Frequency	50Hz
Power	500W(Sterilize)/ 170W(Dry)

Name of Components:
Please check if any part is missing after opening the sales package.



107*145mm 铜版纸175g行标加厚